





## **Crossbar Installation Guide**

Please read all installation guide before using this product.



















- A. Metal box x4
- B. Screw x12
- C. Nut x12
- D. Washer x12
- E. Wrench
- F. Ring x12
- G. End cap x4
- H. Bar x2

1



Slide 2 nuts horizontally into the groove of the bar, direction of the bar does not matter. Do this for the other bar.

**Note:** Remove the foam on the nut if there is difficulty inserting the nut into the groove

2





Lock two boxes to each bar with the screw and washer combo using L-wrench.

**Note:** Box can slide freely to adjust position before you fully tighten the screw

**Note:** If there is difficulty connecting box to bar, remove the nut from the bar, loosely tighten to the box, then insert the nut+box to the groove

3



Put on end caps to the bars, then tighten in the 2 screws to the sides of each cap.





Load bars onto the truck bed for the final step. Insert 4 nuts into each rail. Lock all 4 boxs to the nuts on the rail with one screw, ring, and washer using L-wrench. Done!

**Note:** If there is any difficulty opening or closing the cover after this step, loose the bar-box screw a little will help.